



Product manual

# Pressure louvers

AFZM



Air distribution

Version 1.0.1  
Date: 17.06.2024.

# AFZM

## Aluminum fixed louver

- Made out of anodized aluminium profiles
- Galvanized steel mesh on the back side
- Fixing with screws
- Free cross-section approx. 50 % of B x H



- ▼ [Product overview](#)
- ▼ [Ordering key](#)
- ▼ [Maintenance](#)



PRODUCT OVERVIEW


AIRFLOW REGULATION




### OPTIONS

- RAL...

### DIMENSIONS

B x H				
<b>B</b>	297	-	1197	in increments 100 mm
<b>H</b>	197	-	497	in increments 100 mm
*all combinations B x H are possible				



-  [Product overview](#)
-  [Ordering key](#)
-  [Maintenance](#)



## ORDERING KEY

## AIRFLOW REGULATION

### ORDERING KEY

(1) Pressure louver      (2) Dimensions [mm]      (3) Material finish

**AFZM - 297 x 197 - RAL**

(1) Pressure louver:  
**AFZM**

(2) Dimensions: **297-1197 x 197-497** [mm]

(3) Material finish: **RAL**



- ▼ [Product overview](#)
- ▼ [Ordering key](#)
- ▼ [Maintenance](#)



## TRANSPORT

After arrival, check the louver for transport damage and shortcomings. In case of any damage or shortcomings, immediately contact your supplier.

## STORAGE

If the louver is not installed immediately:

- Remove any wrapping.
- Protect louver from dust and contamination.
- Do not expose the louver to the effects of weather, store the louver in a dry place.

**Please properly dispose of packaging material!**

## MAINTENANCE AND OPERATION

Klimaoprema louvers are designed as such do not require cleaning and regular maintenance.

- After each intervention, provide a systematic cleaning of dust
- Cleaning instruction: clean with a sponge, with water or a mild detergent

It is not permitted to alter the louvers in any way nor perform any changes to their structure without the manufacturer's consent. The functional test must be carried out in compliance with the basic maintenance principles of the European norm.

## COMMISSIONING

- Carefully unpack - be careful of sharp edges and do not use excessive force for unpacking
- Before commissioning - check the product functions



## AIRFLOW DISTRIBUTION

---

Projektiranje, proizvodnja i održavanje opreme za klimatizaciju, ventilaciju i čiste prostore.  
Design, production and service of Ventilation, Air-Conditioning and Clean room equipment.

---

-  Gradna 78A, 10430 Samobor, Croatia
-  +385 (0)1 33 62 513
-  [info@klimaoprema.com](mailto:info@klimaoprema.com)
-  [www.klimaoprema.com](http://www.klimaoprema.com)